

## WAGAN Corp. Limited Warranty Registration Form

All WAGAN Corporation products are warranted to the original purchaser of this product. Warranty Duration: This product is warranted to the original purchaser for a period of one (1) Year from the original purchase date, to be free of defects in material and workmanship. WAGAN Corporation disclaims any liability for consequential damages. In no event will WAGAN Corporation be responsible for any amount of damages beyond the amount paid for the product at retail. In the even of a defective item, please ship the item, prepaid, with a complete explanation of the problem, your name, address and daytime phone number. WAGAN Corporation will, at its option, replaces or repair the defective part. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA and does not extend to any units which have been used in violation of written instructions furnished.

Warranty Disclaimers: This warranty is in-lieu of all warranties expressed or implied and no representative or person is authorized to assume any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to negligence, gross negligence, strict liability, breach of warranty and breach of contract.

Warranty Performance: During the above one (1) Year warranty period, a product with a defect will be replaced with a comparable model when the product is returned to WAGAN Corporation with an original store receipt. The replacement product will be in warranty for the balance of the one (1) Year warranty period.

- Please activate my limited warranty for WAGAN Corp. 15 Liter Personal Fridge / Warmer
- Enclosed copy of original sales receipt.

Name		
Mail Address		
City		
State, Zip Code		
Item Purchased	15 Liter Personal Fridge / Warmer	
Stores Name		
Date of Purchase		
Signature		Date

All WAGAN Corporation Products must be registered within (30) days of purchased to activate this warranty. Mail the complete registration form, along with a copy of the original receipt to:

Attn: Customer Service  
 WAGAN Corporation  
 3589 Yale Way  
 Fremont, CA 94538

© 2004 WAGAN Corp.



Item no. 2031

# 15 Liter Personal Fridge / Warmer™



***User's Manual***

# 15 Liter Personal Fridge / Warmer by Wagan Tech

USER'S MANUAL — Please read before using this equipment.

Thank you for purchasing the 15 Liter Personal Fridge / Warmer by Wagan Tech. With normal care and proper treatment it will provide years of reliable service. Please read all operating instructions carefully before use.



## SPECIFICATIONS

Item No.	2031
Capacity	15 Liters
Weight	4.5 Kg
Power Consumption	48-54 Watts
Voltage	DC12V
Current	5 Amp
Cooling	About 20° C (68° F) below ambient temperature 25° C (77° F)
Warming	About 65° C (149° F) above ambient temperature 25° C (77° F)
Accessories	DC12V power cord

\*CAUTION: Do not use for extended periods, as it may damage the unit


## INSTRUCTIONS FOR USE

### Setting Up


1. Open the display box of the cooler
2. Take the cooler out of the polybag
3. Remove the power cord from the polybag
4. Insert the power cord to the socket

### Operation for Car Use


1. Start the engine of the vehicle first
2. Make sure the cooler power switch is in the off position
3. Connect the power cord to the cooler
4. Plug the other end of the power cord into cigarette lighter receptacle and rotate to make a good electrical contact
5. Choose the hot or cool operation by pushing the switch left or right to desired – Red light for warming, green light for cooling
6. Normally the cooler will take 45 minutes to become cool or warm
7. When the unit is completely cool or warm, the temperature will drop gradually when the power cord is disconnected



Insert power cord into Cooler socket




Start the Engine



Plug the power lead adaptor into the lighter socket firmly

## When Using at Home

1. A special AC adaptor is available for indoor use
2. Do not use AC adaptor in the following places:
  - i. Muddy or cement ground
  - ii. Humid areas
  - iii. Damp ground (e.g. basement)
  - iv. Other high moisture locations



## Disconnection

1. Turn the switch to the OFF position
2. Remove the power cord from the cigarette lighter of the vehicle
3. Wait at least 30 minutes until the unit is completely cool

## Troubleshooting

1. If the cooler does not work, check the fuse. If broken, replace with new 5 Amp fuse

## Cleaning and Storage

1. Wait at least 30 minutes until the cooler is completely cooled down
2. Clean your cooler with mild household cleaner
3. Store in a safe place away from children

## THINGS YOU SHOULD KNOW

Use a small tool to select COOL or OFF or WARM

Switch off and wait for 30 minutes before switching from cool to hot or vice versa. Failure to do so will generate a non-functioning state and shorten the life of the cooler

Do not touch the aluminum part inside when the switch is ON, it may burn  
Do not use in poorly ventilated area

- Good ventilation is essential to avoid overheating
- The inside fuse may be damaged and lose its power
- Do not cover the vent when cooler is operating

Both ends of power cord must be plugged in. Do not plug power cord into power source before plugging in the appliance first

Make sure to unplug the car plug power cord first before turning off the engine of the vehicle

Do not immerse in any water or other liquids

Don't plug in the lighter socket of DC24 volt system commonly found on trucks or buses

Use an adaptor (not provided) to convert DC24 volts to DC12 volts to use with DC24 volt system